



Screws supplied are suitable for fixing hooks to a minimum 30mm thick timber substrate. We recommend hooks are spaced at 300mm centres.

safehook  
— AUSTRALIA —